

## BATERIE PATONA PRO ACER 4400MAH



Cena celkem:	<b>1 050 Kč</b> <b>(bez DPH: 868 Kč)</b>
Běžná cena:	<b>1 155 Kč</b>
Ušetříte:	<b>105 Kč</b>
Kód zboží:	PORB0007
Part No.:	PT2121
Záruka:	24 měsíců/6 měs. akku
Stav:	Nové zboží

## Popis

### PATONA baterie pro Acer 4400 mAh

Kompatibilní baterie pro notebooky Acer. Baterie se vyznačují vysokou kvalitou, mají integrovanou ochranu proti přetížení a přebíjení. Nutno dodržet napětí originální baterie!!

### ZÁKLADNÍ SPECIFIKACE

**Kapacita:** 4400 mAh

**Technologie baterie:** Li-iontová

**Nahrazuje baterie:** 3UR18650Y-2-CPL-ICL50, 934T2180F, 934T2180F BT.00603.033, AS07B31, AS07B32, AS07B4, AS07B41, AS07B42, AS07B51, AS07B52, AS07B61, AS07B7, AS07B71, AS07B72, AS07B75, AS07BX1, AS07BX2, B053R012-9002, BT.00603.033, BT.00603.042, BT.00604.018, BT.00604.025, BT.00605.015, BT.00605.021, BT.00606.001, BT.00607.010, BT.00607.016, BT.00803.024, BT.00804.020, BT.00804.024, BT.00805.011, BT.00807.014, BT.00807.015, BTP-AS5520G, BTP-AS5520G ICK70, ICK70, ICK70, ICL50, ICL50, ICW50, ICY70, JDW50, JDW50 MS2221, LC.BTP00.007, LC.BTP00.008, LC.BTP00.013, LC.BTP00.014, MS2221, ZD1

**Pro notebooky:** Acer Aspire 5220 Series, Acer Aspire 5220G, Acer Aspire 5230, Acer Aspire 5235, Acer Aspire 5300, Acer Aspire 5310 Series, Acer Aspire 5315, Acer Aspire 5315G, Acer Aspire 5320, Acer Aspire 5320 Series, Acer Aspire 5330, Acer Aspire 5520 Series, Acer Aspire 5520G Series, Acer Aspire 5530, Acer Aspire 5535 Series, Acer Aspire 5710 Series, Acer Aspire 5710G, Acer Aspire 5710Z, Acer Aspire 5710ZG, Acer Aspire 5715, Acer Aspire 5715Z, Acer Aspire 5720 Series, Acer Aspire 5720G, Acer Aspire 5720Z Series, Acer Aspire 5720ZG, Acer Aspire 5730, Acer Aspire 5730Z, Acer Aspire 5730G, Acer Aspire 5730ZG, Acer Aspire 5735, Acer Aspire 5735Z, Acer Aspire 5739, Acer Aspire 5739G, Acer Aspire 5910 Series, Acer Aspire 5920 Series, Acer Aspire 5920G Series, Acer Aspire 5930, Acer Aspire 5930G, Acer Aspire 5935, Acer Aspire 5935G, Acer Aspire 5940, Acer Aspire 5940G, Acer Aspire 5942, Acer Aspire 5942G, Acer Aspire 6530, Acer Aspire 6530G, Acer Aspire 6920 Series, Acer Aspire 6920G Series, Acer Aspire 6930, Acer Aspire 6930G Series, Acer Aspire 6930ZG, Acer Aspire 6935, Acer Aspire 6935G, Acer Aspire 7220, Acer Aspire 7230, Acer Aspire 7235, Acer Aspire 7320 Series, Acer Aspire 7330, Acer Aspire 7520 Series, Acer Aspire 7520G Series, Acer Aspire 7520Z Series, Acer Aspire 7530, Acer Aspire 7530G, Acer Aspire 7535, Acer Aspire 7540, Acer Aspire 7540G, Acer Aspire 7720 Series, Acer Aspire 7720G Series, Acer Aspire 7720Z Series, Acer Aspire 7730, Acer Aspire 7730Z, Acer Aspire 7730G, Acer Aspire 7730ZG, Acer Aspire 7735, Acer Aspire 7735Z, Acer Aspire 7735ZG, Acer Aspire 7736, Acer Aspire 7736Z, Acer Aspire 7736G, Acer Aspire 7736ZG, Acer Aspire 7738, Acer Aspire 7738G, Acer Aspire 7740, Acer Aspire 8530, Acer Aspire 8730, Acer Aspire 8730G, Acer Aspire 8730Z, Acer Aspire 8730ZG, Acer Aspire 8735G, Acer Aspire 8735ZG, Acer Aspire 8920 Series, Acer Aspire 8920G Series, Acer Aspire 8930 Series, Acer Aspire 8930G, Acer Aspire 8935, Acer Aspire 8935G, Acer Aspire 8940, Acer Aspire 8940G, Acer Aspire 8942, Acer Aspire 8942G, Acer Aspire Z Serie, Acer Aspire ZG-3A1G16Mi, Acer Aspire 584G32Bn, Acer Aspire 734G32Bn, Acer Aspire 844G32Bn, Acer Aspire 864G32Bn, Acer Aspire 864G64Bn, Acer Aspire 944G64Bn, Acer eMachines E510, Acer eMachines E520, Acer eMachines E720, Acer eMachines G420, Acer eMachines G520, Acer eMachines G620, Acer eMachines G720, Acer Extensa 7230, Acer Extensa 7630, Acer Extensa 7630G, Acer TravelMate 7230, Acer TravelMate 7330, Acer TravelMate 7530, Acer TravelMate 7530G, Acer TravelMate 7730, Acer TravelMate 7730G, Packard Bell EasyNote LJ61

Series, Packard Bell EasyNote LJ63 Series, Packard Bell EasyNote LJ65 Series, Packard Bell EasyNote LJ67 Series, Packard Bell EasyNote LJ71 Series, Packard Bell EasyNote LJ73 Series, Packard Bell EasyNote LJ75 Series